

## STANDARD and EXTENDED WARRANTY REFERENCE GUIDE

Model #				Unit Size	Controller	Standard Warranty Coverage	5 Year Extended Warranty Code	5 Year Extended Warranty Coverage	7 Year Extended Warranty Code	7 Year Extended Warranty Coverage	10 Year Extended Warranty Code	10 Year Extended Warranty Coverage
6518	6519	6561	6998	7kW (PowerPact)	Digital LED	Y 1&2 = Parts & Labor Y 3 = Parts only	EXTWRTYAIR2013 DEW-EXWAR100001	Years 1, 2, 3, 4, 5 = Parts and Labor	EXTWRTYAIR7C DEW-EXWAR100002	Years 1 to 7 = Parts and Labor	EXTWRTYAIR10C DEW-EXWAR100003	Years 1 to 10 = Parts and Labor
5870	5871	5882		8kW	Nexus	Y 1&2 = Parts & Labor Y3 = Parts only	EXTWRTYAIR  (Can no longer be purchased)	Years 1, 2, 3, 4 = Parts and Labor  Year 5 = Parts only	Not available	Not available	Not available	Not available
6051	5883		10kW									
6052	5884		14kW									
6053	5885		17kW									
5874	5886		17kW									
	5875	5887		20kW								
6237	7029	6245		8kW	Evolution	Y 1&2 = Parts & Labor  Y 3 = Parts only Y 4&5 = Engine/Alt Parts ONLY	EXTWRTYAIR2013 DEW-EXWAR 100001	Years 1, 2, 3, 4, 5 = Parts and Labor	EXTWRTYAIR7C DEW-EXWAR 100002	Years 1 to 7 = Parts and Labor	EXTWRTYAIR10C DEW-EXWAR 100003	Years 1 to 10 = Parts and Labor
7030			9kW									
6437	6438	6439	720	11kW								
7031	7032	7033		11kW								
6240	6241	6247		14kW								
6461	6462	6459	6721	16kW								
7035	7036	7037		16kW								
6242	6243	6248	6249	17kW								
6244	6250	6729	6730	20kW								
7038	7039			20kW								
6551	6552	7042	7043	22kW								
6055	6098	7040	7042	20kW Synergy (VSCF)	Evolution	Y 1&2 = Parts & Labor Y 3 = Parts only Y 4&5 = Engine/Alt Parts ONLY	EXTWRTYAIR2013 DEW-EXWAR 100001	Years 1, 2, 3, 4, 5 = Parts and Labor	Not available	Not available	Not available	Not available
QT02224	QT02515	QT02724	QT03015	22kW	Nexus	Years 1 and 2 = Parts and labor	EXTWRTYLCSM2013 DEW-EXWAR 200001	Years 1, 2, 3, 4, 5 = Parts and Labor	EXTWRTYLCSM7C DEW-EXWAR 200002	Years 1 to 7 = Parts and Labor	EXTWRTYLCSM10C DEW-EXWAR 200003	Years 1 to 10 = Parts and Labor
QT03624	QT04524	QT04854		25kW								
				27kW								
				30kW								
				36kW								
				45kW								
QT06024				60kW	Nexus	Y1 = Parts & Labor Y2 = Parts only	EXTWRTYLCSM2013 DEW-EXWAR 200001	Years 1, 2, 3, 4, 5 = Parts and Labor	EXTWRTYLCSM7C DEW-EXWAR 200002	Years 1 to 7 = Parts and Labor	EXTWRTYLCSM10C DEW-EXWAR 200003	Years 1 to 10 = Parts and Labor
QT07068	QT08054	QT10068	QT13068	70kW	Nexus	Y1 = Parts & Labor  Y2 = Parts only	EXTWRTYLCLG2013 DEW-EXWAR 200004	Years 1, 2, 3, 4, 5 = Parts and Labor	EXTWRTYLCLG7C DEW-EXWAR 200005	Years 1 to 7 = Parts and Labor	EXTWRTYLCLG10C DEW-EXWAR 200006	Years 1 to 10 = Parts and Labor
QT15068				80kW								
				100kW								
				130kW								
				150kW								
				Last letter = "X" or "C" only								
RD015	RD020	RD030	RD048	RG027	Evolution	Y 1&2 = Parts & Labor Y 3 = Parts only Y 4&5 = Engine/Alt Parts ONLY	EXTWRTYLCSM2013 DEW-EXWAR 200001	Years 1, 2, 3, 4, 5 = Parts and Labor	EXTWRTYLCSM7C DEW-EXWAR 200002	Years 1 to 7 = Parts and Labor	EXTWRTYLCSM10C DEW-EXWAR 200003	Years 1 to 10 = Parts and Labor
RD025	RD035	RD045		RG030								
RD040	RD050	RD060		RG036								
				RG038								
				RG045								
				RG048								
				RG060								
Future RG Gaseous  70-150 kW				RG series  70 - 150 kW	Evolution	Y 1&2 = Parts & Labor Y 3 = Parts only Y 4&5 = Engine/Alt Parts ONLY	EXTWRTYLCLG2013 DEW-EXWAR 200004	Years 1, 2, 3, 4, 5 = Parts and Labor	EXTWRTYLCLG7C DEW-EXWAR 200005	Years 1 to 7 = Parts and Labor	EXTWRTYLCLG10C DEW-EXWAR 200006	Years 1 to 10 = Parts and Labor

## IMPORTANT NOTES:

- 1> All warranties (standard and extended) are always retroactive to the startup date of the generator
- 2> Once an extended warranty is purchased and invoiced it can not be exchanged, refunded, credited, or swapped under any circumstance
- 3> Extended warranties can not be applied to Honeywell product with a Nexus controller, reconditioned units, EcoGen, Corepower, Siemens, or Eaton branded units
- 4> Once an extended warranty is applied to a unit, no further (or longer) extended warranties can be applied to the unit